

CARE AND MAINTENANCE FOR ALL CAMBRO GOBAG® MODELS

Thank you for purchasing a Cambro GoBag.

SAFETY INFORMATION:



CAUTION

- Follow all food safety guidelines. Food must be at the appropriate temperature before being placed into the bag. Use a temperature probe to check internal food temperature.
- Not designed for direct food contact.
- Do not use canned fuel or open flame inside or near the bag.
- Bags are designed to hold food at temperature for up to 45 minutes
- Allow hot metal pan surfaces to cool below 170°F (77°C) before placing inside the bag.

CLEANING INSTRUCTIONS:

- Clean daily using a damp cloth or sponge with warm water and any mild soap.
- Wipe up food spills as soon as possible to avoid staining and difficult-to-clean conditions.
- To eliminate odor, use a vinegar and water solution to clean the inside of the bag.
- Allow to air dry or use a towel.
- Do not use abrasive cleaners or cleaners containing bleach.
- Bags without vinyl interior are machine washable. Air dry do not put in the dryer.

Save this document for future reference