

DT131 Instructions

Directions for the thermometer:

- 1. Press the ON/OFF button to activate the thermometer. The thermometer will automatically turn off after 10 minutes of inactivity.
- 2. Hand wash the thermometer with soap and water before putting back into sleeve.

°F/°C Selection:

1. Press the °F/°C button to switch from Fahrenheit to Celsius.

Maximum Memory:

- Press the MAX button to display the maximum temperature reading. Press the MAX button again to return to the default measurement mode.
- 2. To clear the maximum reading, press and hold the MAX button for 3 seconds.

Hold Button:

1. To hold the current temperature reading, pres the HOLD button. The thermometer will hold and display the temperature reading from when the button is pushed, until the HOLD button is pressed again.

Calibrating the Thermometer:

- 1. Put the thermometer into an ice slurry.
- 2. Once the temperature is stabilized, press the CAL button for 2 seconds, "CAL" will appear on the display of 2 seconds. The thermometer will auto-calibrate and then return to normal mode.
- 3. Calibration van only take place when the temperature is between 23°F to 41°F / -5°C to 5°C

Replacing the Battery

Change the battery when the LCD dims or does not display a reading.

1. Remove the battery cover by using a screwdriver. Remove the battery and insert the new battery (1 x LR44) with positive (+) polarity facing up.